

# Radar Signal Processing Mastery

Theory and Hands-On Applications with mmWave MIMO Radar Sensors

*Date: 7-11 October 2024*

*Time: 9:00AM-11:00AM ET (New York Time)*



Mohammad Alae-Kerahroodi

Research scientist

SnT, University of Luxembourg

Email: [Mohammad.alae@uni.lu](mailto:Mohammad.alae@uni.lu)

Website: <https://radarmimo.com/>

# Outline

Time: 9:00AM-11:00AM ET (New York Time)

Lecture	Duration	Date
Lecture 1: Radar Systems Fundamental	2 Hours	October 7 <sup>th</sup> , 2024
Lecture 2: Advanced Radar Systems	2 Hours	October 8 <sup>th</sup> , 2024
Lecture 3: Practical Radar Signal Processing - Motion Detection	2 Hours	October 9 <sup>th</sup> , 2024
Lecture 4: Practical Radar Signal Processing - Breathing and Heart Rate Estimation	2 Hours	October 10 <sup>th</sup> , 2024
Lecture 5: Practical Radar Signal Processing – Angle estimation with MIMO radar	2 Hours	October 11 <sup>th</sup> , 2024

# Lecture 3

*Motion Detection with Infineon BGT60LTR11AIP*

# Lecture 3: Motion Detection with Infineon BGT60LTR11AIP

*What we learn in Lecture 3*

- **Getting started with BGT60LTR11AIP**
- **Doppler and Micro-Doppler effects**
- **Motion detection principle**
- **Real-time data measurement**
- **Signal processing and motion detection**


- ☐ Doppler and Micro-Doppler
- ☐ Radar Target Classification based on Micro-Doppler




Scan the QR code for  
access to the codes

# Recall from lecture 1 - CW Radar

*Doppler Effect*



$$s_{rx}(t) = A_r \cos(\omega_r t + \phi_r)$$



# Infineon DEMO BGT60LTR11AIP

Product	Description
BGT60LTR11AIP	XENSIV™ 60 GHz first completely autonomous radar sensor for motion sensing
BGT60LTR11SAIP	XENSIV™ 60 GHz first completely autonomous radar sensor for motion sensing
DEMO BGT60LTR11AIP	XENSIV™ BGT60LTR11AIP 60 GHz radar sensor pulsed Doppler demo board
SHIELD_AUTONOM_BGT60	Shield for autonomous operation of BGT60LTR11AIP; directly fits on Arduino MKR board
REF BGT60LTR11AIP M0	Reference design with Cortex®-M0 MCU for data processing
S2GO RADAR BGT60LTR11	Shield2Go version
BGT60TR13C	XENSIV™ 60 GHz radar sensor for advanced sensing
DEMO BGT60TR13C	XENSIV™ 60 GHz radar sensor demo board for advanced sensing
BGT60UTR11AIP	XENSIV™ highly integrated 60 GHz FMCW radar sensor
DEMO BGT60UTR11AIP	XENSIV™ BGT60UTR11AIP 60 GHz radar sensor FMCW demo board

# Infineon DEMO BGT60LTR11AIP

<https://www.infineon.com/cms/en/product/evaluation-boards/demo-bgt60ltr11aip/>



Parametrics	DEMO BGT60LTR11AIP
Antenna	Antennas in package
Board Type	Demo Board
Direction of Motion	Yes
Field of View	90
Frequency min max	61 GHz 61.5 GHz
Max Detection Range	11 m
Min Detection Range	0.6 m
Number of Rx Antennas	1
Number of Tx Antennas	1
Target Application	Automated door openers ; Contactless switches ; Displays such as TVs ; monitors ; laptops or tablets ; Lighting systems and lighting control (mainly indoor lighting) ; Multicopter and drones ; Smart Building ; Smart appliances ; Smart home security and alarm systems including IP cameras ; Smart Home devices ; Air conditioners







# Infineon DEMO BGT60LTR11AIP

<https://www.infineon.com/cms/en/product/evaluation-boards/demo-bgt60ltr11aip/>

**BGT60LTR11AIP MMIC**



**BGT60LTR11AIP Shield**



**DEMO BGT60LTR11AIP**

= Radar Baseboard MCU7  
+ BGT60LTR11AIP Shield






# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

<https://www.infineon.com/cms/en/product/evaluation-boards/demo-bgt60ltr11aip/#!designsupport>

Development Tools

	Development Tools <b>Radar Development Kit</b>	 Infineon	<a href="#">&gt; Read More</a>
	Development Tools <b>Radar Fusion GUI</b>	 Infineon	<a href="#">&gt; Read More</a>


# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board



# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board



NT




# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board




Releases Quickstart **Software** Hardware Documentation

## Radar Development Kit

Run "Radar Development Kit"




# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board



Releases Quickstart Software Hardware Documentation

## Software

### Radar Software Development Kit (SDK)

 [radar\\_sdk.zip](#)

The Radar SDK is used to evaluate the following XENSIV™ Radar sensors.:

- FMCW Radars
  - BGT60 UTR11AIP
  - BGT60 TR13C
  - BGT60 ATR24C
- Doppler Radars
  - BGT60 LTR11AIP

Radar SDK allows users to configure and fetch raw data from above mentioned XENSIV™ radar sensors using C/C++, Python and Matlab programming languages. In addition, it contains sophisticated propriety algorithms to solve target detection and localization use-cases, and some useful tools to e.g. data recording and flash firmware etc.

Name




- 3rd\_party
- build
- cmake
- CMakeFiles
- doc
- examples
- external
- libs
- python\_wheels
- sdk
- tools
- CMakeCache
- CMakeLists
- VERSION

- ifxradarsdk-3.5.0+8c595dbb-py3-none-linux\_armv7l.whl
- ifxradarsdk-3.5.0+8c595dbb-py3-none-linux\_x86\_64.whl
- ifxradarsdk-3.5.0+8c595dbb-py3-none-macosx\_10\_14\_universal2.whl
- ifxradarsdk-3.5.0+8c595dbb-py3-none-win\_amd64.whl

```
cd C:\path\to\your\whl\file

pip install ifxradarsdk-3.5.0+8c595dbb-py3-none-win_amd64.whl
```

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board





# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

```
from ifxradarsdk import get_version
from ifxradarsdk.ltr11 import DeviceLtr11
from ifxradarsdk.ltr11.types import Ltr11Config
```

$$f_c = 60 \text{ GHz}$$

$$\lambda = 0.005 \text{ m}$$

$$\text{assume } v_r = 1 \frac{\text{m}}{\text{s}}$$

$$f_d = \frac{2v_r}{\lambda} = \frac{2}{0.005} = 400 \text{ Hz}$$

```
prt_index = 1 # 0 = 4000 Hz, 1 = 2000 Hz, 2 = 1000 Hz, 3 = 500 Hz
if prt_index == 0:
    sample_rate = 4000
elif prt_index == 1:
    sample_rate = 2000
elif prt_index == 2:
    sample_rate = 1000
else:
    sample_rate = 500
```

Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

## “Radar Fusion GUI”

Threshold ⓘ  80

### Radar Sensor Settings

RF Center Frequency ⓘ  [MHz]

Pulse Width ⓘ  [μs]

Pulse Repetition Time ⓘ  [μs]

Rx IF Gain ⓘ  [dB]

Tx Power Level ⓘ  0 7

☐ Tx1 P: 4.5 [dBm]

☐ Rx1

```
config = Ltr11Config(  
    aprt_factor=4,  
    detector_threshold=80,  
    disable_internal_detector=False,  
    hold_time=8,  
    mode=0, # 0: continuous wave mode, -- 1: pulse mode  
    num_of_samples=num_of_samples,  
    prt=prt_index,  
    pulse_width=3,  
    rf_frequency_Hz=61044000000,  
    rx_if_gain=8,  
    tx_power_level=7,  
)
```

Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

```
#
~~~~~
~~~~~

# Initialization
ENABLE_I_Q_PLOT = True
sample_time = 1/sample_rate
num_of_samples = 256
window_time = 1 # second
buffer_time = 5 * window_time # second
figure_update_time = 25 # m second
num_rx_antennas = 1
raw_data_size = int(buffer_time * sample_rate)
IQ_xaxis = np.linspace(1, buffer_time, raw_data_size)
epsilon_value = 0.00000001
#
~~~~~
~~~~~
```

Initialize the parameters

Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

Initialize the data queue

```
# data queue
data_queue = queue.Queue()
#
~~~~~
~~~~~

def read_data(device):
    while True:
        frame_contents = device.get_next_frame()
        for frame in frame_contents:
            data_queue.put(frame)
#
~~~~~
~~~~~
```

Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

```
class myProcessorClass:
    def process_data(self):
        global raw_data
        while True:
            time.sleep(1/sample_rate)
            if not data_queue.empty():
                frame = data_queue.get()
                if np.size(frame) == num_of_samples:
                    raw_data = np.roll(raw_data, -num_of_samples)
                    raw_data[-num_of_samples:] = frame

#
~~~~~
~~~~~
```

Define the process class

Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

Create plot

```
def generate_iq_plot():
    plot = pg.plot(title='Inphase and Quadrature')
    plot.showGrid(x=True, y=True)
    plot.setLabel('bottom', 'Time [s]')
    plot.setLabel('left', 'Amplitude')
    plot.addLegend()
    plots = [
        ('lightblue', 'Inphase [I]'),
        ('gold', 'Quadrature [Q]')
    ]
    plot_objects = [[] for _ in range(len(plots))]
    for j, (color, name) in enumerate(plots):
        line_style = {'color': color, 'style': [QtCore.Qt.SolidLine, QtCore.Qt.DashLine, QtCore.Qt.DotLine][0]}
        plot_obj = plot.plot(pen=line_style, name=f'{name}')
        plot_obj.setVisible(True)
        plot_objects[j].append(plot_obj)
    return plot, plot_objects

# Usage:
if ENABLE_I_Q_PLOT:
    iq_figure, I_Q_PLOT = generate_iq_plot()
    iq_figure.show()
```

Lect3\_example1\_BGT60LTR11AIP.py



# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

Update plot by timer

```
def update_plots():
    if ENABLE_I_Q_PLOT:
        I_Q_PLOT[0][0].setData(IQ_xaxis, np.real(raw_data))
        I_Q_PLOT[1][0].setData(IQ_xaxis, np.imag(raw_data))
    #
    ~~~~~
    ~~~~~

#
~~~~~
~~~~~

timer = QTimer()
timer.timeout.connect(update_plots)
timer.start.figure_update_time) # Update the plots based on figure_update_time
#
~~~~~
~~~~~
```

Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

## Connect to sensor

```
if __name__ == "__main__":
    # ~~~~~
    # connect to the device
    pp = pprint.PrettyPrinter()
    with DeviceLtr11() as device:
        print("Radar SDK Version: " + get_version())
        print("Sampling Frequency [Hz]: ", sample_rate)

        sampling_frequency = device.get_sampling_frequency(prt_index)
        config_defaults = device.get_config_defaults()

        config = Ltr11Config(
            aprt_factor=4,
            detector_threshold=80,
            disable_internal_detector=False,
            hold_time=8,
            mode=0, # 0: continuous wave mode, -- 1: pulse mode
            num_of_samples=num_of_samples,
            prt=prt_index,
            pulse_width=3,
            rf_frequency_Hz=61044000000,
            rx_if_gain=8,
            tx_power_level=7,
        )
        device.set_config(config)
```

Lect3\_example1\_BGT60LTR11AIP.py

## Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board

Start the data\_thread and process\_thread

```
# initialization
raw_data = np.zeros(raw_data_size, dtype=np.complex128)
#
~~~~~
~~~~~


# Threads for reading data and processing
data_thread = threading.Thread(target=read_data, args=(device,))
data_thread.start()

radar_processor = myProcessorClass()
process_thread = threading.Thread(target=radar_processor.process_data, args=())
process_thread.start()
#
~~~~~
~~~~~

sys.exit(app.exec_())
```


Lect3\_example1\_BGT60LTR11AIP.py

# Getting started with the XENSIV™ 60GHz BGT60LTR11AIP radar sensor demo board



Lect3\_example1\_BGT60LTR11AIP.py

# Record Data Demo BGT60LTR11AIP



Lect3\_example1\_BGT60LTR11AIP.py



# Recorded Data Demo BGT60LTR11AIP



Lect3\_example2.m





# Recorded Data Demo BGT60LTR11AIP




Lect3\_example3.m

# Micro Doppler with BGT60LTR11AIP



Lect3\_example4.m

# I and Q Modulator in CW Radar



$$\bar{s}_{rx}(t) = A_r e^{(j2\pi f_d t)}$$

# Micro-Doppler

$$\bar{s}_{rx}(t) = A_r e^{(j2\pi f_d t)}$$


$$f_d = \frac{2v_r}{\lambda} = \frac{2}{\lambda} \left( v_{target} + \sum_{i=1}^n v_{component,i} \right)$$

$v_{target}$  : Velocity of the main target


$v_{component,i}$  : Velocity of the  $i$ -th moving component contributing to the micro-Doppler effect

$n$  : number of components contributing to the micro-Doppler signature

# Chest Movement Effect



# Chest Movement Effect



$$\phi(t) = \frac{2\pi}{\lambda} 2R(t) = \frac{4\pi}{\lambda} (R_0 + x(t))$$

Distance to  
radar

Chest + heart + body movement

$$x(t) = x_h(t) + x_c(t) + x_b(t)$$

Heart


Chest

Body

	Displacement (mm)
Heartbeat	0.15 – 0.5
Chest	0.01 – 0.15



# Chest Movement Effect



$$\phi(t) = \frac{2\pi}{\lambda} 2R(t) = \frac{4\pi}{\lambda} (R_0 + x(t))$$

Distance to radar

Chest + heart + body movement

$$x(t) = x_h(t) + x_c(t) + x_b(t)$$


Heart

Chest

Body

	Displacement (mm)
Heartbeat	0.15 – 0.5
Chest	0.01 – 0.15

# Chest Movement Effect



$$\bar{s}_{rx}(t) = A_r e^{(j\phi(t))} = I + jQ$$

$$\hat{\phi} = \arctan \frac{Q}{I}$$

$$f_c = 60 \text{ GHz}$$


$$\lambda = 0.005 \text{ m}$$

$$\text{Displacement (mm)} = 0.5 \text{ mm} = 0.005 \text{ m}$$

$$\Delta\phi \geq \frac{4\pi}{0.005} 0.005 = 4\phi$$

Folding happens

# Breathing Rate Estimation



I and Q signal


Phase angle estimation

Phase unwrap

Appropriate Filtering


Breathing and Heart  
Rate Estimation  
(Spectrum Analysis)

# Breathing Rate Estimation




Lect3\_example5\_BGT60LTR11AIP.py

# Breathing Rate Estimation



Lect3\_example6.m

# Breathing Rate Estimation



Lect3\_example7.m


# Breathing Rate Estimation



Lect3\_example7.m




# Breathing Rate Estimation




Lect3\_example7.m

# Breathing Rate Estimation



Lect3\_example7.m

# Breathing Rate Estimation



Lect3\_example6\_BGT60LTR11AIP.py

# What we learned from Lecture 3

- In Lecture 3 we used BGT60LTR11AIP to capture real data and processed it to extract Doppler, micro-Doppler and breathing pattern of human. Different signal processing techniques to this end has been applied in real-time operation.



Scan the QR code for  
access to the codes

Q & A

Using a FMCW radar, how can we better monitor vital signs of human?